UPS Socomec "NETSYS RT2 1100", Online, Tower/rack, 900 W, fara AVR, IEC x 6, display LCD, back-up 1 - 10 min. "NRT2-U1100" (timbru verde 11 lei) Importator: Royal Computers, Bucuresti Str. Culcer Ioan 32, tel: 021.410.21.00

UPS Socomec "NETSYS RT2 1100", Online, Tower/rack, 900 W, fara AVR, IEC x 6, display LCD, back-up 1 - 10 min. "NRT2-U1100" (timbru verde 11 lei) Importator: Royal Computers, Bucuresti Str. Culcer Ioan 32, tel: 021.410.21.00

UPS Socomec "NETSYS RT2 1100", Online, Tower/rack, 900 W, fara AVR, IEC x 6, display LCD, back-up 1 - 10 min. "NRT2-U1100" (timbru verde 11 lei) Importator: Royal Computers, Bucuresti Str. Culcer Ioan 32, tel: 021.410.21.00

UPS Socomec "NETSYS RT2 1100", Online, Tower/rack, 900 W, fara AVR, IEC x 6, display LCD, back-up 1 - 10 min. "NRT2-U1100" (timbru verde 11 lei) Importator: Royal Computers, Bucuresti Str. Culcer Ioan 32, tel: 021.410.21.00

UPS Socomec "NETSYS RT2 1100", Online, Tower/rack, 900 W, fara AVR, IEC x 6, display LCD, back-up 1 - 10 min. "NRT2-U1100" (timbru verde 11 lei) Importator: Royal Computers, Bucuresti Str. Culcer Ioan 32, tel: 021.410.21.00

UPS Socomec "NETSYS RT2 1100", Online, Tower/rack, 900 W, fara AVR, IEC x 6, display LCD, back-up 1 - 10 min. "NRT2-U1100" (timbru verde 11 lei) Importator: Royal Computers, Bucuresti Str. Culcer Ioan 32, tel: 021.410.21.00

UPS Socomec "NETSYS RT2 1100", Online, Tower/rack, 900 W, fara AVR, IEC x 6, display LCD, back-up 1 - 10 min. "NRT2-U1100" (timbru verde 11 lei) Importator: Royal Computers, Bucuresti Str. Culcer Ioan 32, tel: 021.410.21.00

UPS Socomec "NETSYS RT2 1100", Online, Tower/rack, 900 W, fara AVR, IEC x 6, display LCD, back-up 1 - 10 min. "NRT2-U1100" (timbru verde 11 lei) Importator: Royal Computers, Bucuresti Str. Culcer Ioan 32, tel: 021.410.21.00

UPS Socomec "NETSYS RT2 1100", Online, Tower/rack, 900 W, fara AVR, IEC x 6, display LCD, back-up 1 - 10 min. "NRT2-U1100" (timbru verde 11 lei) Importator: Royal Computers, Bucuresti Str. Culcer Ioan 32, tel: 021.410.21.00

UPS Socomec "NETSYS RT2 1100", Online, Tower/rack, 900 W, fara AVR, IEC x 6, display LCD, back-up 1 - 10 min. "NRT2-U1100" (timbru verde 11 lei) Importator: Royal Computers, Bucuresti Str. Culcer Ioan 32, tel: 021.410.21.00

UPS Socomec "NETSYS RT2 1100", Online, Tower/rack, 900 W, fara AVR, IEC x 6, display LCD, back-up 1 - 10 min. "NRT2-U1100" (timbru verde 11 lei) Importator: Royal Computers, Bucuresti Str. Culcer Ioan 32, tel: 021.410.21.00

UPS Socomec "NETSYS RT2 1100", Online, Tower/rack, 900 W, fara AVR, IEC x 6, display LCD, back-up 1 - 10 min. "NRT2-U1100" (timbru verde 11 lei) Importator: Royal Computers, Bucuresti Str. Culcer Ioan 32, tel: 021.410.21.00

UPS Socomec "NETSYS RT2 1100", Online, Tower/rack, 900 W, fara AVR, IEC x 6, display LCD, back-up 1 - 10 min. "NRT2-U1100" (timbru verde 11 lei) Importator: Royal Computers, Bucuresti Str. Culcer Ioan 32, tel: 021.410.21.00

UPS Socomec "NETSYS RT2 1100", Online, Tower/rack, 900 W, fara AVR, IEC x 6, display LCD, back-up 1 - 10 min. "NRT2-U1100" (timbru verde 11 lei) Importator: Royal Computers, Bucuresti Str. Culcer Ioan 32, tel: 021.410.21.00

UPS Socomec "NETSYS RT2 1100", Online, Tower/rack, 900 W, fara AVR, IEC x 6, display LCD, back-up 1 - 10 min. "NRT2-U1100" (timbru verde 11 lei) Importator: Royal Computers, Bucuresti Str. Culcer Ioan 32, tel: 021.410.21.00

UPS Socomec "NETSYS RT2 1100", Online, Tower/rack, 900 W, fara AVR, IEC x 6, display LCD, back-up 1 - 10 min. "NRT2-U1100" (timbru verde 11 lei) Importator: Royal Computers, Bucuresti Str. Culcer Ioan 32, tel: 021.410.21.00

UPS Socomec "NETSYS RT2 1100", Online, Tower/rack, 900 W, fara AVR, IEC x 6, display LCD, back-up 1 - 10 min. "NRT2-U1100" (timbru verde 11 lei) Importator: Royal Computers, Bucuresti Str. Culcer Ioan 32, tel: 021.410.21.00

UPS Socomec "NETSYS RT2 1100", Online, Tower/rack, 900 W, fara AVR, IEC x 6, display LCD, back-up 1 - 10 min. "NRT2-U1100" (timbru verde 11 lei) Importator: Royal Computers, Bucuresti Str. Culcer Ioan 32, tel: 021.410.21.00

UPS Socomec "NETSYS RT2 1100", Online, Tower/rack, 900 W, fara AVR, IEC x 6, display LCD, back-up 1 - 10 min. "NRT2-U1100" (timbru verde 11 lei) Importator: Royal Computers, Bucuresti Str. Culcer Ioan 32, tel: 021.410.21.00

UPS Socomec "NETSYS RT2 1100", Online, Tower/rack, 900 W, fara AVR, IEC x 6, display LCD, back-up 1 - 10 min. "NRT2-U1100" (timbru verde 11 lei) Importator: Royal Computers, Bucuresti Str. Culcer Ioan 32, tel: 021.410.21.00

UPS Socomec "NETSYS RT2 1100", Online, Tower/rack, 900 W, fara AVR, IEC x 6, display LCD, back-up 1 - 10 min. "NRT2-U1100" (timbru verde 11 lei) Importator: Royal Computers, Bucuresti Str. Culcer Ioan 32, tel: 021.410.21.00

UPS Socomec "NETSYS RT2 1100", Online, Tower/rack, 900 W, fara AVR, IEC x 6, display LCD, back-up 1 - 10 min. "NRT2-U1100" (timbru verde 11 lei) Importator: Royal Computers, Bucuresti Str. Culcer Ioan 32, tel: 021.410.21.00